



Theory and measurements of wide-band fiber-optic links

James W Lamb

Owens Valley Radio Observatory


Caltech





- link losses are typically 30–40 dB
- loss greater for shorter wavelength laser

- Photon noise
 - Poisson statistics
- Thermal noise
 - Johnson noise in matching resistor
- Amplifier noise
 - From low noise amplifier after link
- Laser noise
 - RIN (relative intensity noise)
 - other sources of amplitude fluctuations
 - laser technology-dependent



intrinsic photodiode impedance is high, so use parallel resistor to match

$$R_s \cong R_L = 50 \Omega$$

1 photon \rightarrow 1 electron
 photon noise = shot noise

$$P_{\text{phot}} = \eta q P_{\text{opt}} e^{-1} \sqrt{R_{\text{RF}}} / 2 h \nu L_{\text{opt}}$$

output noise temperature

$$T_{\text{out}} = P_{\text{phot}} / k + T_{\text{amb}} + T_{\text{amp}}$$

for just the link: $T_{\downarrow \text{link}} = T_{\downarrow \text{out}} L_{\downarrow \text{link}}$



high link loss means input noise temperature is very high

for the link including preamp:

$$T_{\downarrow \text{link}} = T_{\downarrow \text{out}} L_{\downarrow \text{link}} / G_{\downarrow \text{preamp}} + T_{\downarrow \text{preamp}}$$

we can make the amplifier gain large, to make $T_{\downarrow \text{link}} \rightarrow T_{\downarrow \text{preamp}}$




HOWEVER: we cannot increase $G_{\downarrow \text{amp}}$ indefinitely, otherwise we will saturate the link




$$DR = P_{\downarrow\text{sat}} / P_{\downarrow\text{noise}} \downarrow_{\text{out}}$$



- $P_{\downarrow\text{sat}}$
 - proportional to: $P_{\downarrow\text{opt}}^{\uparrow 2}, L_{\downarrow\text{opt}}^{\uparrow -2}, \nu^{\uparrow -2}$
- $P_{\downarrow\text{noise}}$
 - proportional to: $P_{\downarrow\text{opt}}, L_{\downarrow\text{opt}}, \nu$
- dynamic range
 - proportional to: $P_{\downarrow\text{opt}} / \nu^{\uparrow -3} L_{\downarrow\text{opt}}^{\uparrow 2}$


Measurement setup






OTX:	Optilab LT-20
ORX:	Optilab LR-30








- to get the best dynamic range, should have uniform SNR across band
- need to *pre-emphasize* input

The image cannot be displayed. Your computer may not have enough memory to open the image, or the image may have been corrupted. Restart your computer, and then open the file again. If the red x still appears, you may have to delete the image and then insert it again.





The image cannot be displayed. Your computer may not have enough memory to open the image, or the image may have been corrupted. Restart your computer, and then open the file again. If the red x still appears, you may have to delete the image and then insert it again.



- fiber optical links capable of wide-bandwidth transmission
- performance close to theoretical from fundamental physics
- for best performance
 - keep optical losses low
 - use highest optical power (NB: safety issues)
 - pre-emphasize signal to give uniform SNR

Thank you!